

RAK475 UART WiFi Module

Instruction Manual V1.2

Shenzhen Rakwireless Technology Co., Ltd.

www.rakwireless.com

info@rakwireless.com

© RAK copyright. All rights reserved.

Companies and product names referred in the instruction belong to trademarks of their respective owners.

Any part of this document may not be reproduced, and may not be stored in any retrieval system, or delivered without RAK's written permission.

The document will be updated without prior notice.

Content

1. Rapid usage	5
1.1 Introduction to the development board	5
1.2 The method for the module to reset to Factory Defaults	6
1.3 Inspection prior to powering on	7
1.4 The status after powering on	7
1.5 Transparent transmission data test	9
2. Function features	11
2.1 Overview	11
2.2 Application fields	11
2.3 Product features	11
3. Instruction encyclopedia	13
3.1 Network configuration method	13
3.2 Web page configuration	14
3.2.1 Module status	14
3.2.2 Network settings	16
3.2.3 Communication settings	20
3.2.4 Certificate management	22
3.2.5 Equipment management	23
3.2.6 Firmware upgrading	23
3.3 App wireless configuration	24
3.4 Instant configuration	25
4. Aided AT commands	27
4.1 Basic flow chart	27
4.2 AT command set	28
4.3 Command Format	29
4.4 Enter into aided commands	30

4.5	Module management instruction	32
4.5.1	Open ASCII display	32
4.5.2	Query the module's MAC address	32
4.5.3	Enter into the transparent transmission mode	33
4.5.4	Query the software version	34
4.5.5	Reset to restart the module	35
4.5.6	Reset to Factory Defaults	36
4.6	Parameter configuration instruction	37
4.6.1	Write user configuration	37
4.6.2	Read the user configuration	38
4.6.3	Reproduce the user configuration	39
4.6.4	Read Factory Defaults	40
4.6.5	Read Factory Defaults	41
4.7	AP STA operating instruction	42
4.7.1	Query the connection status of STA	42
4.7.2	Query the connection status of AP	43
4.7.3	The wireless signal intensity of STA	44
4.7.4	Scan the wireless network	45
4.7.5	Get the wireless network	47
4.7.6	EasyConfig networking	49
4.7.7	WPS networking	50
4.7.8	Query IP inFormation	51
4.7.9	Ping command	52
4.7.10	Query TCP connection status	53
4.7.11	Query the connected network inFormation	53
4.8	Instruction for receiving and sending the data	54
4.8.1	Send data	54

4.8.2 Receive data.....	56
4.9 Read and write NVM data.....	57
4.9.1 Write data to NVM.....	57
4.9.2 Read NVM data.....	59
4.10 Command for setting the certificate.....	60
4.10.1 Set ssl security certificate.....	60
4.11 InFormation storage commands for the user networking list.....	61
4.11.1 Read the number of current list.....	61
4.11.2 Read the networking inFormation in the indicated lists.....	62
4.11.3 Write the networking inFormation to the indicated lists.....	63
4.11.4 Delete the networking inFormation in the indicated lists.....	64
4.12 Upgrading of serial port firm ware.....	65
4.12.1 Enter into the upgrading mode.....	65
5. Appendix-configuration parameter encyclopedia.....	67
6. Version.....	72

1. Rapid usage

1.1 Introduction to the development board

RAK475 serial port transparent transmission module focuses on transparent transmission supported by AT Command; it has the advantages of simple operation and rich functions and can meet the requirements of various kinds of customers. First, let's see the usage of RAK475 evaluation suits.

Table 1-1: Development board source

Function	Name	Description
Module	U3	RAK475 transparent transmission WIFI module
External Interface	Micro USB	Input power supplied DC5V, communication interface of USB to serial port
Key	Reset	Module reset key
	WPS/MODE	WPS function is to instantly configured to the network (match with the router' s WPS)
	Default	1. Press the "greater than 3 seconds" module to recover to the Factory Defaults parameters 2. Press the "less than 1 second" , instantly configure the easyconfig mode
Pin	P2	UART and 232 interface
	P6	Reset, Link and other pins
Power Consumption pin	J1	Power consumption measurement interface
LED Indicators	POWER	Power Lamp
	STATUS	Start Running Indicator Lamp
	LINK	Network Indicator Lamp

Table 1-2: LED Definition

	Status	Link	Status
Function	Instant configuration	Flash interval of 200ms	Normally on
	Upgrading of hard wares	Flash interval of 50ms	

STA Mode	Unconnected	Normally off	Normally on
	Connecting to the network	Flash interval of 1 second	
	Getting IP	Flash interval of 2 seconds	
	The network is connected	Normally on	
	Socket event	Flash for three times	
AP mode	AP is not established	Normally off	Normally on
	AP is established, and not connected	Periodically on and off in 1 second	
	STA is connected	Normally on	
Factory Defaults Mode	Recovering Factory Defaults takes effect	Periodically on and off in 500ms	Periodically on and off in 500ms

Note:

- “Status” light is a start light, which is in the normally on status after the module starts regularly.
- After pressing the instant configuration key for less than 1 second, “Link” light flashes until the configuration is successful or of timeout.
- After pressing the recovering Factory Defaults key for more than 3 seconds, “Link” and “Status” are on and off at the same time, and automatically reset after 3 seconds.
- Coexistence of AP and SAT mode, the indicator lamps indicate jointly

1.2 The method for the module to reset to Factory Defaults

There is a “Default” key on the development board, which is used to reset to Factory Defaults for the module when the configuration is made by mistakes or the current configuration parameters are forgotten:

Press the “Default” key for over 3 seconds, the indicator lamp “Link” and “Status” are on and off at the same time, at this time, loose the “Default” key for 3 seconds, the module will reset to the Factory Defaults mode (establish AP by default, and the customer can modify the defaults parameters).

1.3 Inspection prior to powering on

The evaluation suits mainly include: antenna of Micro USB line, development board, IPEX connector interface. If the module is external antenna module, please plug in the antenna. Connect the module' s serial port and computer' s serial port (the USB to serial port of the computer).

1.4 The status after powering on

Normal phenomenon

After the module is powering on, the power indicator lamp (power lamp) lights on, next, the "Status" light is on (the "Status" pins output the low level), it shows that the module starts regularly.

If the "status" light is not on after powering on, please try to press the "Reset" key. If the light is always off, please contact the After-Sale Service.

Under the Factory Defaults mode of the module, an open AP network will be established after powering on, with the name of RAK475_AP_XXXXXX (XXXXXX is the rear six digits of the module's MAC address), IP address of 192.168.7.1, default opening of DHCPSever (the Factory Defaults can be modified). After the "Status" light is on, open the computer's wireless network, RAK475_AP_XXXXXX will be found in the wireless list, as shown below:



Figure 1-1: Factory Defaults AP scanning

1. Double click to join the network (at this time, "Link" will be normally on), wait for well distributed IP address. Open the browser and input the gate address of the module-192.168.7.1, the web page pops up an authentication interface,

inputs the authenticated user name and PIN ("admin" by default).





Figure 1-2: WEB webpage authentication

2. You can see the WEBSever interface with the built-in module.



Figure 1-3: WEB webpage- module status

3. The serial port communication and socket communication settings of the module by default are as shown below:



The screenshot shows the 'IO Set' configuration page. On the left is a sidebar with links: Status, Wlan Set, IO Set (highlighted), SSL Certs, Advance, and Firmware. The main content area is divided into two sections: 'UART Settings' and 'Socket Settings'. Each section has a 'Save' button.

UART Settings

Baudrate	115200
Databit/Checkbit/Stopbit	8 None 1
RTS/CTS	Disable

Socket Settings

Open Double Socket	Close
SocketA Type	TCP-Server
SocketA allow connections num	no limit
SocketA ServerIP(Domain)	
SocketA ServerPort	0
SocketA LocalPort	25000
SocketA TCP idle timeout/recon interval	0 0 (S)

Note : TCPS/C idle timeout,0: disable; TCPC recon interval,0: no interval

Figure 1-4: Default IO communication page

1.5 Transparent transmission data test

1. Open the serial port tools, select the COM port connected to the module. The default baud rate is 115200, data bit is 8, stop bit is 1, with no parity, no flow control. Open network debugging tools (TCP/UDP tool), establish TCP client to connect the IP and port of the other party (the default IP of the module is 192.168.7.1, the server port is 25000).




Figure 1-5: Establish TCP Client

- After TCP is connected, the data can be sent to each other. At this time, the serial port of the module is changed into the virtual serial port of the network, and the serial port data and network data is interconnected.




Figure 1-6: Factory Defaults mode transparent transmission test

2. Function features

2.1 Overview

RAK475 module is an ultra-low power consumption WIFI module which fully supports IEEE802.11b/g/n wireless protocol, and has the advantages of small packaging and easy usage. The module is completely serial port transparent transmission module, inside which integrates TCP/IP protocol stack and driver, the usage is convenient, after simple configuration, it can be used regularly, the module connects the physical serial port and network, and access the connected equipment into the network.

RAK475 module has the advantages of stable performances, ultra-low power consumption, flexible usages, it can meet various customer's requirements, provide various test reports, allow the customer to quickly start so as to reduce the research and development period.

RAK475 module also provides various kinds of customized services, such as user WEB page, production configuration tools, mobile phone APP and the like.

2.2 Application fields

- Portable products
- Household appliance
- Industrial sensor
- POS terminal
- Building automation
- Logistics and freight management
- Household security and automation
- Medical field, for example, patients monitoring, medical diagnosis
- Measurement (parking meter, metering instrument, ammeter and the like)

2.3 Product features

- Meet 802.11b/g/n wireless protocol
- Built in TCP/IP protocol stack
- Support OPEN, WEP, and WPA/WPA2-PSK encryption
- Support SoftAP, Station, and coexistence of SoftAP and Station mode.

- Support TCP, UDP, SSL and other communication protocols
- Support DHCP SERVER、DHCP CLIENT
- Support giving priority to the transparent transmission supplemented by AT commands
- Support the UART communication with the data flow, the maximum baud rate is 921600bps
- Support various configuration tools, and the module can be configured in one step
- Support the wireless upgrading module firm ware
- Board antenna or U.FL antenna connector
- Working voltage: 3.3V
- Support the automatic power saving work mode
- Meet FCC, RoHs and CE authentication

3. Instruction encyclopedia

3.1 Network configuration method

The transparent transmission module aims at data communication in the end, WIFI communication is carried out under the preconditions of parameter configuration, the important thing is the network configuration (network name, PIN and IP address) and which kind of communication protocol socket set (TCP, UDP and SSL security) to use. The module defines the following two concepts for the parameters.

At first, the module defines two parts, namely, Factory Defaults parameters and user parameters.

Factory Defaults parameters: the module maintains the parameters of the initial status when it is not regularly used (generally acts as AP access point), at this time, the module has independent network name, fixed IP address, etc. The Factory Defaults mode ensures the recovery of the module, so as to avoid the problems caused by users' configuration mistakes. (Factory Defaults parameters can be modified by customers)

User parameters: when the module was regularly configured, the module will enable a new configuration to be user parameters as will be automatically loaded when the module resets, the user parameters are the configuration of actual application of customers. (can write once)

In order to transfer from the Factory Defaults mode to the user mode easily, the transparent transmission module provides four kinds of flexible configuration methods to connect to the user' s router:

- Access the Web server with the built-in module via the browser to carry out parameters modification
- Use WPS function to connect with the router rapidly
- Use EasyConfig function to realize the connection with the router

The module supports the coexistence of AP and STA mode, i.e. users can not only connect the module to the router (Internet), but also access and look up the module and the like in the local net via the existing AP network, so as to be greatly convenient for users and enhance the user's experiences.

3.2 Web page configuration

After the module establishes AP or is added to the router, input the module's IP address in the browser's address column, then you can access. Under the AP mode, IP address is gate address by default, for example, 192.168.7.1. Under the STA mode, add the router, if IP address is automatically gotten, the module can get the address from the home page's status bar via the coexisting AP, it can access WEB server as well.

3.2.1 Module status

The module's related information is shown in the module's status, for example, the module's MAC address, module name, software version; parameters in the AP mode and STA mode.

Remote connection status means whether the module is successfully connected to the server's state information when the two-way socket connection of the module acts as a TCP client or SSL client.

The wizard button at the bottom of the page can be configured to navigate, so as to help customers to complete the required configuration in turn. The following configurations refer to the network settings section.

Status	Device status
Wlan Set	Dev-MAC 9C:44:3D:38:A5:5D
IO Set	Dev-name RAK475
SSL Certs	Firmware version 0.0.0.0.7-1.6.1
Advance	Access point ON
Firmware	SSID RAK475_AP_38A55D
	Encryption OPEN
	IP address 192.168.7.1
	Station point ON
	AP SSID RAK_2.4GHz
	AP BSSID 8C:21:0A:D9:EB:7B
	RSSI -57
	Encryption WPA2-AES-PSK
	Password rakwireless205
	IP address 192.168.1.119
	Remote connection
	SocketA Not Used
	SocketB Not Used

★help : Start Wizard will show you configure steps.

[Start Wizard](#)

Figure 3-1 Module status page

Status	Module navigation
Wlan Set	STA Mode : STA mode can be configured to connect the wifi router,only need to enter the router ssid and password.Usually used for WLAN services,and also can be used for cloudservice data applications. AP Mode : AP mode creat an encrypted or open wifi network,like our commonly used wifi router.Usually used in module configuration after factory,and also can be used for collecting sensor data,very simple and practical. AP+STA Mode : AP+STA coexistence mode, means AP is alway on, and can also creat a STA point to connect customer router .Mainly for configuration .Also can be used to work mode, through the AP to view the various states of the module. WLAN Work Mode Work mode : AP+STA Mode ▼ Back Next
IO Set	
SSL Certs	
Advance	
Firmware	

Figure 3-2 Module navigation page

3.2.2 Network settings

WLAN settings are divided into: the choice of the work mode, AP parameters and STA parameter settings.

- WLAN mode: AP, STA and AP+STA mode.
- AP mode: AP mode settings produce an encrypted WIFI wireless network, which is similar to the commonly used wireless router. It is mainly used in the Factory Defaults configuration of the module, and can also be used for data acquisition points with the advantages of simple and practical.
- STA mode: STA mode can be configured to add the home wireless router, the name and password of the router can be filled in for general settings, select DHCP. It is mainly used in local area network service, and can also carry out the remote data application.
- AP +STA mode: coexistence means that when there is a AP hot spot, the module can also act as STA mode to connect to the router. It is mainly used for network configuration and the actual work mode, and can see the status of the module, etc. via the regular AP hot spot.

AP configurations:

- AP SSID: The name length of AP is less than 32 bit.
- whether to broadcast or not: You can select to open or close AP broadcast, closing AP broadcast can hide and increase the safety.
- maximum STA connection number: 1 to 3 can be selected, if you don't care, you may select unlimited, the maximum number (3 by default) can be set in the module.

- Establish the channel: 1-13 can be selected, and you can select automation, automatically select inside the module.
- whether to encrypt or not: open, the encryption can be selected.
- PIN: The length is less than 32 bit
- IP address: Set the gate address of AP mode




Figure 3-3 Parameters page of the module AP

STA configurations:

- Router SSID: The name length of the router is less than 32 bit.

Click "add network", you can select router name to connect from the scanning list sent back by the module, click "OK", then the web page will automatically fill in the selected router name, if the router is encrypted, the prompt box will pop up to prompt to input the password. You can manually enter the name from the router if the router to add is hidden or not scanned.

Click "connected list", you can manage the list of connected networks, remove the network that does not need to be used or no longer exists. This function can save the

configuration of 5 sets of recently connected routers, after enabling the function, the module will firstly connect the router connected last time, if the router connection is not successful, and the module will use the other routers in the list to try to connect. If the connection fails, repeat the above mentioned connection. This feature is not opened by default, it can be enabled via setting the "userlist_en" in FuncBitMap to look the appendix - configuration parameters encyclopedia for details.

- Router BSSID: The MAC address of the router is the only parameter to confirm the router, which is used to differentiate the same router name, if you do not specify the same router or not to use, it can be ignored, fill in 0.
- Whether to encrypt or not: open, the encryption can be selected.
- Route encryption: The length is less than 32
- DHCP option: You can select DHCP settings or static settings, namely, manually input IP address
- IP address: The address which has the same network segment with the router can be selected from the static IP distribution area of the router in the static setting.
- IP mask: It is the same with the router parameters
- IP gate: It has the same parameters with the router; most of them are IP addresses of the router.
- Address of DNS server 1: gate address by default
- Address of DNS server 2: it can fill in known DNS server address

Status
Wlan Set
 IO Set
 SSL Certs
 Advance
 Firmware

WLAN Work Mode

Work mode : AP+STA Mode

+ Access point setting

+ Station setting

Router SSID RAK_2.4GHz
save list +add new

Router BSSID (0: forbidden) 8C:21:0A:D9:EB:7B

Encryption Encrypt

Router password
☐ show

DHCP DHCP

IP address 0.0.0.0

IP mask 0.0.0.0

IP gateway 0.0.0.0

DNS server1 0.0.0.0

DNS server2 0.0.0.0

Save Connect

Figure 3-4 Parameters page of the module STA

Status
Wlan Set
 IO Set
 SSL Certs
 Advance
 Firmware

Please select the WIFI which you connected

	SSID	BSSID	SECTYPE	CHAN	RSSI
☐	seven	1C:FA:68:EB:1F:64	WPA2_PSK_AES	11	-38
☐	raktest	8C:F2:28:8B:11:CA	OPEN	11	-40
☐	rak_only	8C:BE:BE:24:92:A6	WPA2_PSK_AES	05	-44
☐	dlink	48:EE:0C:42:C3:C0	OPEN	01	-44
☐	LTH_E09CF0	62:C5:A8:E0:9C:F0	OPEN	05	-54
☐	LTH_E09C33	62:C5:A8:E0:9C:33	OPEN	09	-54
☐	RAK475_AP_38A5DA	9C:44:3D:38:A5:DB	OPEN	06	-56
☐	link	08:57:00:54:E1:6E	OPEN	01	-56
☐	svn_access	28:2C:B2:87:A7:24	WPA2_PSK_AES	01	-56
☐	RAK475_AP_j	00:E0:4C:87:00:01	OPEN	01	-64
☐	Ur	34:BD:F9:4B:CF:D0	WPA2_PSK_AES	08	-66
☒	RAK_2.4GHz	8C:21:0A:D9:EB:7B	WPA2_PSK_AES	01	-66
☐	ClearB203	88:25:93:81:6F:62	WPA2_PSK_AES	01	-70
☐	cisco-B307	10:BD:18:08:68:4B	WPA2_PSK_AES	06	-76
☐	qingyouzuche	F4:EE:14:26:29:96	WPA2_PSK_AES	11	-76

★Note : When RSSI of the selected WiFi network is lower than 15%, the connection may be unstable, please select other available network or shorten the distance between the device and router.

If your wireless router does "not exist" or "not broadcast", please add a wireless network manually.

Confirm Refresh

Figure 3-5 Module STA adds the network page

3.2.3 Communication settings

Communication settings includes: UART parameter settings and socket parameter settings.

UART parameters configuration

The parameter settings of the serial port includes serial port baud rate, data bit, check bit and stop bit, settings of the flow control. Serial port's free split interval is 10ms, if the timeout for the byte received from the serial port is 10ms, the serial port data with the interval greater than 10ms will be split and sent to the network.

Set the Socket parameters

Socket communication settings, socket parameter settings mainly include the communication socket type, the server's IP address, port number, the local server's port number, TCP timeout and other parameters.

The module supports two communication Sockets, SocketA can act as one of the five secure connections, namely, the TCP server, TCP client, UDP server, UDP client, TLS/SSL secure connection, SocketB does not support a secure connection.

While using the same serial port communication, add two bytes tips to the communication data, "S0" indicates the transceiver data of SocketA, "S1" indicates the transceiver data of SocketB.


IP or domain name of the server can be filled with a fixed IP address or domain name length of less than 42 characters.

The number of connections that Local server supports can set the number of clients connected to the local server, 1-3 can be selected, if you select unlimited, then the default maximum value is 4. When there are multiple connections, the module communication will realize one-to-many communication, the data received from the module serial port will be forwarded to the connected multiple client, take care that

the data of multiple client will be in turn sent from the serial port.

TCP idle timeout parameter indicates that if the TCP connection has not data communication in the set time, the module will take the initiative to close the TCP connection at first and then carry out connection again. This parameter ensures that when the TCP connection is abnormally disconnected, the module can be automatically restored. The time range of the parameter is 1 to 600 seconds.

TCP reconnection interval settings can set delay time for the second connection after TCP connection is off, the user can get a balance in terms of performance and power consumption.




The screenshot shows the 'IO Set' configuration page. On the left is a sidebar with links: Status, Wlan Set, IO Set (selected), SSL Certs, Advance, and Firmware. The main content area is divided into two sections: 'UART Settings' and 'Socket Settings'.
UART Settings:
 - Baudrate: 115200
 - Databit/Checkbit/Stopbit: 8, None, 1
 - RTS/CTS: Disable
 - A 'Save' button is at the bottom right of this section.
Socket Settings:
 - Open Double Socket: Close
 - SocketA Type: TCP-Server
 - SocketA allow connections num: no limit
 - SocketA ServerIP(Domain):
 - SocketA ServerPort: 0
 - SocketA LocalPort: 25000
 - SocketA TCP idle timeout/recon interval: 0, 0 (S)
 - A 'Note' at the bottom states: 'TCPS/C idle timeout,0: disable; TCPC recon interval,0: no interval'.
 - A 'Save' button is at the bottom right of this section.

Figure 3-6 Communication settings page

TLS/SSL secure connection, the protocol type can be optional, namely, SSLV3, TLSV1, TLSV1_1, TLSV1_2, Auto is automatic type, namely, SSL_TLS mixture.

You can choose whether to use a CA certificate or a client certificate. Related certificates can be set in the certificate management.



Socket Settings

Open Double Socket	Close
SocketA Type	TLS-SSL
SocketA protocol/use CA/CLIENT	TLSV1_2 no no
SocketA ServerIP(Domain)	www.baidu.com
SocketA ServerPort	443
SocketA LocalPort	25000
SocketA TCP idle timeout/recon interval	10 5 (S)


Note : TCPS/C idle timeout,0: disable; TCPC recon interval,0: no interval

Save

Figure 3-7 TLS/SSL Set page

3.2.4 Certificate management

Certificate management interface can upload CA certificate, client certificate and client private key file. The status of the certificate is divided into: does not exist, not used and has been used.



Status

Wlan Set

IO Set

SSL Certs

Advance

Firmware

Manage TLS-SSL certs
 You can choose use CA file, verify connected server.
 If server need verify client cert, you should upload client and key cert.
Note : Repeat upload will be covered

Load CA cert

ca status : not exist
 选择文件 未选择任何文件
upload

Load Client cert

client status : not exist
 选择文件 未选择任何文件
upload

Load Client Key

key status : not exist
 选择文件 未选择任何文件
upload

Figure 3-8 IO Communication settings page of the module

3.2.5 Equipment management

In the equipment management, the user name and password for logging on web page can be modified so as to improve the security of the module. Modify the module name, as being the host name of the module can be displayed in the connected router. In the equipment management, the restart and recovering Factory Defaults parameters function buttons are provided.




Figure 3-9 Advanced management page of the module

3.2.6 Firmware upgrading

The module supports the wireless upgrading function to facilitate customers to assess. Please be careful in upgrading, contact RAK technological support if required.

1. WEB upgrading



Figure 3-10 Module firm ware upgrading page

2. PC wireless tools upgrading

Use the wireless upgrade tools of the following PC clients, as long as they are in the same network with module, click on the "scan" to find module, choose the firm ware to upgrade, click "start to upgrade", waiting for the upgrading to complete.




Figure 3-11 PC wireless upgrading page

3.3 App wireless configuration

APP wireless configuration parameters are similar to those of the WEB configuration, add AP network of the module, and open the installed "RAK47XScanConfig" tool of the Android phone, as shown below, configuration methods are as WEB.




Figure 3-12 APP configuration page

3.4 Instant configuration

"RAK47X AP configuration & instant configuration" tool can instantly configure the modules under AP mode to the used network, and can also find and upgrade the module in the same network.

The following demonstrates the instant configuration of RAK475, connect to the 2.4 required to configured, open the software and choose the "RAK475", enter into "Config" page, select SimpleConfig, enter the password, click "Connect", as shown below on the left, waiting for about 10 seconds, the module is successfully configured, connect to the Internet network, pop-up module's MAC address, as shown below on the right.




Figure 3-13 Instant configuration page

4. Aided AT commands

4.1 Basic flow chart

Module's work status gives priority to direct transparent transmission mode, but also provides an auxiliary command mode in order to manage and query the parameters for the module. Module interpret based on the MODE pin level, (high level by default) and enter into the transparent transmission mode. If the pin is low level, then open aided command mode. The aided command mode can be entered at any time. The following is the basic flow chart of the module:




Figure 4-1 Basic flow chart of the module

4.2 AT command set

Table 4-1 AT command set

AT command	Description
Module management instruction	
at+ascii=<mode>\r\n	Open ASCII display
at+mac\r\n	Query the module' s MAC address
at+easy_txrx\r\n	Enter into the transparent transmission mode
at+version\r\n	Query the software version
at+reset \r\n	Reset the module
at+restore\r\n	Resect to Factory Defaults
Parameter configuration instruction	
at+write_config=Configure the parameter length and parameter of \r\n	Write user configuration
at+read_config\r\n	Read the user configuration
at+read_restoreconfig\r\n	Read Factory Defaults
at+write_restoreconfig=Configure the parameter length and parameter of \r\n	Modify the Factory Defaults
at+copy_cfg	Reproduce user configuration to be Factory Defaults configuration
AP SAT operating instruction	
at+con_status\r\n	Query the connection status of STA
at+ap_status\r\n	Query the connection status of AP
at+rssi\r\n	Query the wireless signal intensity of STA
at+scan=<channel>,<ssid>\r\n	Scan the wireless network
at+get_scan=<scan_num>\r\n	Get indicated number of network inFormation
at+easy_config\r\n	The module enters into instant configuration mode
at+wps\r\n	The module starts WPS function, adds the indicated router
at+ipconfig\r\n	Query IP parameters of the module

at+ping=<host>, <count>, <size>\r\n	Ping network host command
at+tcp_status=0\r\n	Query the connection status of TCP
at+net_info\r\n	Query the connected network inFormation
Instruction for receiving and sending data	
at+send_data=0,dest_port,dest_ip,datalen,databuffer\r\n	Send data from Socket
at+recv_data=0,dest_port,dest_ip,datalen,databuffer\r\n	Receive data from Socket
Read and write NVM data	
at+nvm_write=<addr>,<len>,<data>\r\n	Write data to NVM
at+nvm_read=<addr>,<len>\r\n	Read NVM data
Set the certificate command	
at+set_cert=<cert_type>,<file_len>,<data_stream>\r\n	Set ssl security certificate
InFormation storage commands for the user networking list	
at+read_userlist_num\r\n	Read the inFormation number of current list
at+read_userlist=<index>\r\n	Read the networking inFormation in the indicated lists
at+write_userlist=<index>,<len>,<data>	Write the networking inFormation to the indicated lists
at+delete_userlist=<index>\r\n	Delete the networking inFormation in the indicated lists
Firm ware upgrading command	
at+upgrade\r\n	Enter into the upgrading mode

4.3 Command Format

From the host to the module: at+<command>=<parameter 1>, <parameter 2>, <parameter n>\r\n

Parameters included in all the AT commands are all ASCII codes, for example:

at+scan=0,TP-LINK_2.4GHz\r\n

After each piece of command is carried out, the module will send the returned value

with the Format as shown below:

1. If the command is successfully carried out, then the returned values shall be:

OK\r\n or OK<parameter 1><parameter 2>.....<parameter n>\r\n

Note: Besides OK, the other parameters are all hexadecimal system one, for example:

OK\r\n HEX=4F 4B 0D 0A----- No parameter

OK@\r\n HEX=4F 4B 64 0D 0A----- parameter =0x64

2. If the command is unsuccessfully carried out, then the returned values shall be:

ERROR<code>

Note:

- Wherein, ERROR is ASCII code, <code> is hexadecimal system code
ERROR ?\r\n HEX=45 52 52 4F 52 FE 0D 0A-----<code>=0XFE
- AT command Format instruction: AT command begins with "at+" (all are lowercase), and ends with "\r\n", the maximum command length of 80 bytes, and the beginning of any other Formats are wrong orders.
- The above AT command Formats are not applicable to send and receive data commands of at+recv_data and at+send_data, for detailed instructions, please refer to at+recv_data, Instruction part of the at+send_data command.

Error CODE

Code	Instruction
-1	Parameter input error (parameters are unable to identify / missing parameters / too long command / other illegal parameters)
-12	Unknown errors (memories, system and the like)
Others	For details see specific commands

4.4 Enter into aided commands

Under the transparent transmission mode, open the aided command window, use the methods similar to shaking hands.

1. The host computer (host MCU) send "+ + +", request to enter the command mode.
2. Timing for 200ms, wait for the module to return "U" (0x55) , if the module did not return in the specified time, then the timing of 200ms will again send "+ + +", and requests to enter the command mode until the module successfully return "U" (0x55) .It shows that the module is ready to enter into the command mode, waiting for final confirmation (waiting for 3 seconds).
3. Timing for 200ms, wait for the module to return "U" (0x55) , if the module did not return in the specified time, then the timing of 200ms will again send "+ + +", and requests to enter the command mode until the module successfully return "U" (0x55) .It shows that the module is ready to enter into the command mode, waiting for final confirmation (waiting for 3 seconds).




Figure 4-2 Enter into command time sequence

(the module receives "+ + +";
 the module returns 0X55;
 the module receives 0X55, confirms and enters into the command mode.)

4.5 Module management instruction

4.5.1 Open ASCII display

Command

at+ascii=<mode>\r\n

Description

Convert all the command returned value with ASCII display, facilitate the users to debug and be familiar with the AT command. There is no need to open while programming.

Parameter instruction

Parameter	Parameter value	Instruction
<mode>	0	Prohibit conversion
	1	Open conversion

Instruction for returned value

Parameter	Format	Length (byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	Successfully open
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	Error
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.5.2 Query the module's MAC address

Command

at+mac\r\n

Description

Query MAC address inFormation of the module, the coexistence of AP and STA is under STA mode, the MAC under the AP mode by default is MAC+1 under the STA mode.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length (byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
MAC	HEX	6	MAC address
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.5.3 Enter into the transparent transmission mode

Command:

at+easy_txrx\r\n

Description

Send the command to exit the command mode, and enter into the transmission mode.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length (byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.5.4 Query the software version

Command

at+version\r\n

Description

Query the module version, including the software version and the WLAN version.

For example, 0.0.0.1-1.0.1, 0.0.0.1 indicates the software version number, and 1.0.1 indicates WLAN version number.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
	STRING		Character string
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.5.5 Reset to restart the module

Command

at+reset \r\n

Description

The software reset module

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			

OK	ASCII	2	The reset is successful
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.5.6 Reset to Factory Defaults

Command

at+restore\r\n

Description

Recover the module parameters to the Factory Defaults parameters

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	The reset is successful
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR

<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.6 Parameter configuration instruction

For the keywords and its parameters of the following configuration, please see the appendix - configuration parameters encyclopedia".

4.6.1 Write user configuration

Command

at+write_config=<data_length> ,<data_stream>\r\n

Description

Write the user configuration parameters with one step, the user send all the configuration parameters to the module at one-time. Including network model, network parameters, serial port and communication parameters, etc.

The command can also enable or disable the module's advanced feature options, such as the MODE pin function, whether to enable the connection list function or not, etc.

Parameter instruction

Parameter	parameter values	Instruction
<data_length>	length	Length of written configuration parameter
<data_stream>	data	Written configuration parameter

Example

```
at+write_config=963,wlan_mode=1&ap_ssid=RAK475_AP&ap_channel=1&ap_s
ec_mode=1&ap_psk=123456789&.....\r\n
```

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	The reset is successful
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.6.2 Read the user configuration

Command

```
at+read_config\r\n
```

Description

Read the user configuration parameters, and read all the user configuration parameters at one time.

Parameter instruction

NULL

Example

```
at+read_config\r\n
```

OKwlan_mode=2&ap_ssid=RAK475_AP_38A55D&ap_channel=9&ap_sec_mode=0&ap_psk=123456789&ap_max_clts=0&ap_bdcast=1&ap_ip=192.168.7.1&sta_ssid=RAK_2.4GHz&sta_sec_mode=1&sta_psk=rakwireless205&sta_dhcp=1&sta_ip=0.0.0.0&sta_netmask=0.0.0.0&sta_gateway=0.0.0.0&sta_dns1=0.0.0.0&sta_dns2=0.0.0.0&...\r\n

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
	STRING		Character string
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.6.3 Reproduce the user configuration

Command

at+copy_cfg\r\n

Description

Reproduce the user parameters to be Factory Defaults parameters.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	Open successfully
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.6.4 Read Factory Defaults

Command

at+read_restoreconfig\r\n

Description

Read Factory Defaults parameters configuration of the module, returning structure is the same with reading user's configuration.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK

	STRING		Character string
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.6.5 Read Factory Defaults

Command

at+write_restoreconfig=<data_length>,<data_stream>\r\n

Description

Read Factory Defaults parameters configuration of the module, returning structure is the same with reading user's configuration.

Parameter instruction

Parameter	Parameter value	Instruction
<data_length>	length	Written length of written configuration parameter
<data_stream>	data	Written configuration parameter

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK

	STRING		Character string
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.7 AP STA operating instruction

4.7.1 Query the connection status of STA

Command

at+con_status\r\n

Description

If the module works under the STA mode, the command will be used for the wireless network connection status of the module.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	The command was executed successfully
1	HEX	1	0x01: Connected

			0x00: unconnected
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.7.2 Query the connection status of AP

Command

at+ap_status\r\n

Description

If the module works under the AP mode , the command will be used for determining the connection status of the equipment.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	The command was executed successfully
1	HEX	1	0x01: Connected 0x00: unconnected

\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remarks			

4.7.3 The wireless signal intensity of STA

Command

at+rsi\r\n

Description

Querying the wireless network intensity under STA mode will be effective.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
<RSSI>	HEX	1	Signal intensity (negative), for example: -50, the lower the signal intensity, the smaller the returned value.
\r\n	ASCII	2	End character

The command is unsuccessfully carried out				
ERROR	ASCII	5	ERROR	
<CODE>	HEX	1	0XFE=-2	When there is no network connection or the module works under AP mode.
\r\n	ASCII	2	End character	
Remarks				

4.7.4 Scan the wireless network

Command

at+scan=<channel>,<ssid>\r\n

Description

Scan the wireless network through this command, and access the wireless information, including encryption information, channel, signal strength, BSSID, etc.

Parameter instruction

The scan command includes two parameters, wherein <channel> is the specified channel scanning with the value range of 1 to13, if the value is set to 0, Then scan all the channels, <ssid> means scanning the indicated SSID, the parameter can be optional.

Note:

In case of indicating the channel to scan, you can reduce the scanning time.

Parameter	Parameter value	Instruction
-----------	-----------------	-------------

<channel>	0-13	Indicating the channel (1-13) to scan means channel 0 refers to scan all the channels.
<ssid>	The network name	Indicate SSID (optional)

For example:

at+scan=0 \r\n----- Scan all the channels

at+scan=0,RAKwireless\r\n----- Scan the wireless network with the network name of "RAKwireless" in all the channels.

at+scan=8,RAKwireless\r\n----- Scan the wireless network with the network name of "RAKwireless" in channel 8.

at+scan=6 \r\n----- Scan all the SSID in channel 6.

Instruction for returned value

If the command is executed successfully, then it returns OK and the number of wireless networks that are scanned (with maximum of 20). If the user needs to use the network inFormation, you can call the command "at+get_scan" to get.

Note:

When at+ascii=1, the module will return all the inFormation without need to call get_scan to get. Just for looking up easily.

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	Scan to the network
<SCAN NUM>	HEX	1	Number of wireless networks
\r\n	ASCII	2	End character

The command is unsuccessfully carried out				
ERROR	ASCII	5	ERROR	
<CODE>	HEX	1	0XFE=-2	the indicated ssid is not found
\r\n	ASCII	2	End character	
Remark				

4.7.5 Get the wireless network

Command

at+get_scan=<scan_num>\r\n

Description

Read the scanned inFormation from the command, this command must be called after the at+scan scan wireless network command.

Note:

If the wireless network inFormation is not required, the command can be omitted.

Scanned inFormation has been read completely, if reading again, the module will return the error -2, the at+scan command need to be called for scanning again.

Parameters instruction

<scan_num> is the amount of scanned inFormation that are read , if the parameter is greater than the actual scanned amount, then the command will return the actual scanned amount.

Parameter	Parameter value	Instruction
-----------	-----------------	-------------

<scan_num >	>0	Read the scanned inFormation amount
----------------	----	-------------------------------------

For example:

at+get_scan=10\r\n----- Read 10 pieces of wireless network inFormation

Instruction for returned value

Parameter	Format	Length(byte)	Instruction							
The command is successfully carried out										
OK	ASCII	2	Get the inFormation correctly							
<SSID>	HEX	33	SSID							
<BSSID>	HEX	6	BSSID							
<CHANNEL >	HEX	1	Channel							
<RSSI>	HEX	1	signal intensity (negative value)							
<Security Mode>	HEX	1	encryption method							
			b7	b6	b5	b4	b3	b2	b1	b0
			WPA 2	WP A	WE P	802.1 X	PS K	WE P	TKI P	CCM P
\r\n	ASCII	2	End character							
The command is unsuccessfully carried out										
ERROR	ASCII	5	ERROR							

<CODE>	HEX	1	0xFE=-2	canned inFormation have fully been read
\r\n	ASCII	2	End character	
Remark	b7-b5: encryption method b4-b3: encryption type b2-b0: encryption algorithm			

4.7.6 EasyConfig networking

Command

at+easy_config\r\n

Description

Send the command, the module enters into an instant configuration mode, waiting for the phone to send configuration inFormation. Customers can query whether the network is connected or not through querying network status command.

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	Connect to the network
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR

<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remark			

4.7.7 WPS networking

Command

at+wps\r\n

Description

Send the command; the module enters into the WPS configuration mode, while pressing the router's WPS button, generally WPS' s configuration timeout period is 2 minutes. Customers can query whether the network is connected or not through querying network status command.

Instruction for returned value

Parameter	Forma t	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	Connect to the network
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remark			

4.7.8 Query IP inFormation

Command

at+ipconfig\r\n

Description

Query the current module' s MAC address inFormation, IP address, subnet mask, gateway, DNS server, etc., if the DHCP is not assigned while setting; check out the module address of 127.0.0.1.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	success query
<MAC>	HEX	6	module' s MAC address
<IP>	HEX	4	module' s IP address
<NETMASK>	HEX	4	module' s subnet mask
<GATEWAY>	HEX	4	gateway
<DNS SERVER1>	HEX	4	DNS server 1
<DNS SERVER2>	HEX	4	DNS server 2
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	0XFC=-2 query failed

\r\n	ASCII	2	End character
Remark			

4.7.9 Ping command

Command

at+ping=<host>, <count>, <size>\r\n

Description

Execute Ping command, and test whether the network is connected or not.

Parameter instruction

Parameter	Instruction
<HOST>	Indicated host
<COUNT>	Quantity of the data packets, with default value of 1 (optional)
<SIZE>	Size of data packet, the maximum data packet has 1000bytes with default value of 64bytes.(optional)

For example

at+ping =192.168.1.1\r\n----- execute ping

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	The network has been connected
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	0XFE unable to access the

			=-2	target host.
\r\n	ASCII	2	End character	
Remark				

4.7.10 Query TCP connection status

Command

at+tcp_status=<uuid>\r\n

Description

Query TCP Client connection status corresponding to uuid. Uuid=0 represents SocketA; uuid=1 represents SocketB.

Return:

OK<code>\r\n

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	success query
<code>	ASCII	1	code=0,Not connected code=1,Connected
\r\n	ASCII	2	End character

4.7.11 Query the connected network inFormation

Command

at+net_info\r\n

Description

Read the current network parameters, all the network parameters will be read at one time and returned back to the corresponding structure.

Example

```
OKwlan_mode=2&sta_ssid=RAK_2.4GHz&sta_bssid=8C:21:0A:D9:EB:7B&sta_sec_mode=1&sta_psk=rakwireless205&sta_dhcp=1&sta_ip=192.168.1.119&sta_netmask=255.255.255.0&sta_gateway=192.168.1.1&sta_dns1=192.168.1.1&sta_dns2=0.0.0.0ap_ssid=RAK475_AP_38A55D&ap_channel=9&ap_sec_mode=0&ap_psk=123456789&ap_max_clts=0&ap_bdcast=1&ap_ip=192.168.7.1
```

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
	STRING		Character string
/r/n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remark			

4.8 Instruction for receiving and sending the data

4.8.1 Send data

Command

at+send_data=<uuid>,<dest_port>,<dest_ip>,<data_length> ,<data_stream>\r\n

Description

Send data to the target connection (port identifier) through the command, with the maximum data length of 1024, wherein <data_stream> can be any Format of the data, the module will keep the original data and send without carrying out any process. If the connection is a TCP connection, wherein the target IP and target port can be ignored, filling in 0 will be ok. When the connection is UDP, if not specified, you can fill in 0, if you need to send to the specified target as LUDP, fill in the target IP and destination port number.

Parameters instruction

Parameter	Parameter value	Instruction
< uuid>	0	Indicate socketA
	1	Indicate socketB
<dest port>	1-65535	Target port (ASCII)
<dest ip>	0.0.0.-255.255.255.255	Target IP address (ASCII)
<data_length>	1-1004	Data length (ASCII)
<data_stream>	data	Data to sent (HEX)

For example:

at+send_data=0,0,0,4,ABCD\ r\n----- send 4bytes of data to the connection with the identifier of 0, the data content is "ABCD" .

Instruction for returned value

Parameter	Format	Length(b)	Instruction
-----------	--------	-----------	-------------

		yte)	
The command is successfully carried out			
OK	ASCII	2	The data was sent successfully
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	Data transmission failed
<CODE>	HEX	1	0XFE=-2 Indicated socket is not existed
			0XFD=-3 the data is sent by mistakes
\r\n	ASCII	2	End character
Remark			

4.8.2 Receive data

Command

at+recv_data=<uuid>,<dest_port>,<dest_ip>,<data_length>,<data_stream>\r\n

Description

Receives the UUID data of the corresponding Socket (A, B), when the ASCII display is disabled, receive 16 Decimal system data. The sequence is the same. Suggest using ASCII to display disable mode when programming.

If socket is set to the UDP type, the UDP receives a packet of less than 1024B per packet. Most of them will be discarded. UDP sending end need to set the sending packet's maximum length.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
<CMD>	ASCII	13	Command header
< uuid>	HEX	1	=0X00-0X01 Socket identifier
<dest_port>	HEX	2	destination port (low byte is in the front)
<dest_ip>	HEX	4	target IP
<data_length>	HEX	2	data length (low byte is in the front)
<data_stream>	HEX	<data_lengt h>	Data
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
<CMD>	ASCII	13	Command header
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remark			

4.9 Read and write NVM data

4.9.1 Write data to NVM

Command

at+nvm_write=<addr>,<len>,<data>\r\n

Description

Write data to the indicated address in NVM via the command. The command includes three parameters, the scope of <addr> is 0 to 160K, <len> is the length of the written data with the maximum of 1024Byte, <data> is the written data.

Parameter instruction

Parameter	Parameter value	Instruction
<addr>	0-(163840-1)	Initial address of the written data
<len>	1-1024	The maximum data length is 1024 byte (ASCII)
<data>	data	Written data (HEX)

For Example:

at+nvm_write=1,4,ABCD\r\n----- Write the data "ABCD" to the unit with the initial address of 1.

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	Open successfully
\r\n	ASCII	2	End character

The command is unsuccessfully carried out				
ERROR	ASCII	5	ERROR	
<CODE>	HEX	1	0XFE = -2	Data write failed
\r\n	ASCII	2	End character	
Remark				

4.9.2 Read NVM data

Command

```
at+nvm_read=<addr>,<len>\r\n
```

Description

Read the data that the NVM indicates the address.

Parameter instruction

Parameter	Parameter value	Instruction
<addr>	0-(163840-1)	Read the initial address of data.
<len>	1-1024	The maximum data length is 1024 byte (ASCII)

For Example:

at+nvm_read=1,4\r\n----- Read 4 bytes of data from the unit of initial address of 1.

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
-----------	--------	--------------	-------------

The command is successfully carried out				
OK	ASCII	2	Open successfully	
<data_length>	HEX	2	Length of actually returned data	
<data_stream>	HEX	<data_length>	Data	
\r\n	ASCII	2	End character	
The command is unsuccessfully carried out				
ERROR	ASCII	5	ERROR	
<CODE>	HEX	1	0XFE =-2	Failed to read data
\r\n	ASCII	2	End character	
Remark				

4.10 Command for setting the certificate

4.10.1 Set ssl security certificate

Command

at+set_cert=< cert_type>,<file_len>,<data_stream>\r\n

Description

The command is used to set ssl security certificate

Parameter instruction

Parameter	Parameter value	Instruction
< cert_type>	0	SSL Client Private Key
	1	SSL Client Certificate

	2	SSL CA Certificate
<file_len>	<4*1024	Certificate length

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	The security certificate is set successfully
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remark			

4.11 InFormation storage commands for the user networking list

4.11.1 Read the number of current list

Command

at+read_userlist_num\r\n

Description

Read the number of currently saved networking inFormation list.

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
NUM	HEX	1	List number (0-4)
/r/n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remark			

4.11.2 Read the networking information in the indicated lists

Command

at+read_userlist=<index>\r\n

Description

Read the networking information in the current list

Parameter instruction

Parameter	Parameter value	Instruction
<index>	0-4	Indicate the list to read the networking information

For example:

OKsta_ssid=RAK_2.4GHz&sta_sec_mode=1&sta_psk=rakwireless205&sta_bssid=8C:21:0A:D9:EB:7B\r\n

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
InFormation read successfully			
OK	ASCII	2	OK
	STRING		Character string
\r\n	ASCII	2	End character
InFormation read failed			
<CMD>	ASCII	13	Command header
<CODE>	HEX	0XFE=-2	Invalid storage inFormation
\r\n	ASCII	2	End character
Remark			

4.11.3 Write the networking inFormation to the indicated lists

Command

at+write_userlist= <index>,<len>,<data>\r\n

Description

Write the networking inFormation to the indicated lists

Parameter instruction

Parameter	Parameter value	Instruction
-----------	-----------------	-------------

<index>	0-4	Indicate the list to read the networking inFormation
<len>	Data length	The data length of the networking inFormation
<data>	data	networking inFormation

For example:

```
at+write_userlist=0,85,sta_ssid=RAK_2.4GHz&sta_sec_mode=1&sta_psk=rakwireless205&sta_bssid=8C:21:0A:D9:EB:7B\r\n
```

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	For details see ERROR list
\r\n	ASCII	2	End character
Remark			

4.11.4 Delete the networking inFormation in the indicated lists

Command

```
at+delete_userlist = <index>\r\n
```

Description

Delete the networking inFormation in the current list

Parameter instruction

Parameter	Parameter value	Instruction
<index>	0-4	Indicate the list to delete the networking inFormation

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	OK
/r/n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	0XFE=-2	Invalid stored inFormation
\r\n	ASCII	2	End character
Remark			

4.12 Upgrading of serial port firm ware

4.12.1 Enter into the upgrading mode

Command

at+upgrade\r\n

Description

The command is used to set the module to enter into the upgrading mode.

1. The host computer (host MCU) send at+upgrade\r\n to the module, and request to enter into the upgrading mode.
2. Until the command is executed successfully, the module returns "OK" , the host computer (host MCU) sends "u" to confirm entering into the upgrading mode. If the module executing the command did not return "OK", return to carry out step 1.
3. Until the module return "OKC" , utilize xmodem protocol to send firm ware to the module. If the module did not return "OKC", returned to carry out step 1 to 3

Parameter instruction

NULL

Instruction for returned value

Parameter	Format	Length(byte)	Instruction
The command is successfully carried out			
OK	ASCII	2	Open successfully
\r\n	ASCII	2	End character
The command is unsuccessfully carried out			
ERROR	ASCII	5	ERROR
<CODE>	HEX	1	Invalid stored inFormation
\r\n	ASCII	2	End character
Remark			

5. Appendix-configuration parameter encyclopedia

Table 5-1 Configuration parameter table

Keywords	Parameter	Remarks
Mode selection		
wlan_mode	0: STA mode 1: AP mode 2: Coexistence AP and STA mode	
AP mode parameter		
ap_ssid	RAK475_AP_SSID	SSID name is less than 32B
ap_channel	6	Channel range (1-13)
ap_sec_mode	0: No encryption 1: Encryption	
ap_psk	1234567890	The PIN is between 8B and 32B
ap_ip	192.168.7.1	
ap_bdcast	0: No broadcast 1: Broadcast	
ap_max_clts	The maximum connection number of AP	The maximum is 3
STA mode parameter		
sta_ssid	RAK_AP_STA	SSID name is less than 32B
sta_bssid	8C:21:0A:D9:EB:7B	
sta_sec_mode	0: No encryption 1: Encryption	
sta_sec_type	0: OPEN 1: WEP-PSK 2: WEP-SHARED 3: WPA-TKIP-PSK 4: WPA-AES-PSK 5: WPA2-AES-PSK 6: WPA2-TKIP-PSK 7: WPA2-MIXED-PSK 8 UNKNOWN	
sta_psk	1234567890	The PIN is between 8B and 32B
sta_dhcp	0: Static setting 1: Dynamic acquisition	

sta_ip	192.168.1.100	
sta_netmask	255.255.255.0	
sta_gateway	192.168.1.1	
sta_dns1	192.68.1.1	
sta_dns2	0.0.0.0	
UART communication parameter		
uart_baudrate	9600,19200,38400,57600,115200,230400,460800,921600	
uart_datalen	8	(5-8)
uart_parity_en	0: No 1: Odd parity check 3: Even parity check	
uart_stoplen	1	(1-2)
uart_rtscts_en	0: disable 1: enable	
uart_timeout	5	Timeout time unit for the serial port to be frame: ms The serial port is recommended to send interval per 10ms, the minimum interval is 5ms.
uart_recvlenout	512	When the serial port receives the byte of no less than 512, the module carry out forwarding
FuncBitMap		
mode_pin	wps: wps function easy: Mode selection function	Multiple function pin
userlist_en	0: User list is not enabled 1: User list is enabled	
web_switch	0: Use the original factory's web page 1: Use the customer's web page	unused
web_en	0: WEB (English by default) 1: WEB (Chinese by default)	

web_func_en	0: Disabled WEB configuration 1: Enable WEB configuration	unused
local_find_en	0: Local discovery is disabled 1: Local discovery is enabled	Mdns function is opened by default
first_user_switch	0: disable 1: enable	When the user is configured from the Factory Defaults parameter to the user parameter, the configured router is not able to connect, switch to the Factory Defaults parameter
last_user_switch	0: disable 1: enable	When the user is configured from the current user parameters to another parameter, the configured route is not able to connect, whether switch to the current user parameter or not.
Power consumption mode		
power_mode	0: Full power consumption 1: Automatically saving	
Socket communication		

parameter		
socket_multi_en	Socket communication parameter 1: Double socket	
SocketA parameter		
socketA_type	0: tcpc 1: ltcp 2: udpc 3: ludp 4: tls/ssl	
socketA_tls_v	0: auto 1: SSLV3 2: TLSV1 3: TLSV1_1 4: TLSV1_2	Tls version Auto is the mixture of TLS SSL
socketA_tls_ca	0: disable 1: enable	Tls ca certificate is enabled
socketA_tls_clt	0: disable 1: enable	Tls client certificate is enabled
socketA_max_clts	2	The maximum connecting number of Tcp server The maximum number is 4
socketA_localport	25000	(1-65535)
socketA_destip	192.168.1.101	IP or domain name
socketA_destport	25000	(1-65535)
socketA_tcp_timeout	0: disable 1-600 : valid	TCP idle timeout time unit: s
socketA_tcp_reconnect	0: disable 1-600 : valid	Interval time unit of TCP reconnection: s
SocketB parameter		
socketB_type	0: tcpc 1: ltcp 2: udpc 3: ludp	
socketB_max_clts	2	The maximum connecting number of Tcp server The maximum

		connecting number of Tcp server
socketB_localport	25001	(1-65535)
socketB_destip	192.168.1.101	
socketB_destport	25001	(1-65535)
socketB_tcp_timeout	0: disable 1-600 : valid	TCP idle timeout time unit: s
socketB_tcp_reconnect	0: disable 1-600 : valid	Interval time unit of TCP reconnection: s
Module name		
module_name	RAK475	(16B)
WEB setting		
user_name	admin	(16B)
user_password	admin	(16B)

6. Version

Version	Date	Modified records
V1.0	2016-3-1	Create a document
V1.1	2016-5-6	Add sections 3-3, 3-4
V1.2	2017-4-5	Add" Query TCP connection status"