


# 前面板



- |                       |                     |
|-----------------------|---------------------|
| ① 电源指示灯               | ⑦ USB口              |
| ② 电源操作键 (⏻)           | ⑧ 后退跳读/前进跳读键 (⏮, ⏭) |
| ③ PURE DIRECT (纯直入) 键 | ⑨ 停止键 (■)           |
| ④ 遥控感应窗               | ⑩ 播放键 (▶)           |
| ⑤ 显示屏                 | ⑪ 光碟托盘              |
| ⑥ 光碟托盘打开/关闭键 (⏏)      |                     |